

PRIOR TO INSTALLATION:

- OPEN and thoroughly inspect all mural panels for defects.
- VERIFY all wall and product measurements.
- CHECK walls for bowing, sagging or uneven surfaces as these may cause panels to misalign.
- STOP immediately and contact your representative if any discrepancy is discovered.

While this product is warranted against all manufacturing defects, 4walls.com cannot be responsible for improper installation or problems arising from defects in the construction, surface, or preparation of the wall. See reverse for complete warranty information.

NOTE: Murals & Accent Murals are shipped with unprinted selvage around the all edges that requires trimming during installation.

wall preparation

Murals & Accent Murals may be applied to any dry, clean, smooth surface. Old wallpaper or other surface materials should be removed before application.

Fill cracks with a spackling compound or plaster patching and sand to a smooth surface. Glossy or enamel finish walls should be lightly sanded, then washed with a common household detergent and then allowed to dry completely. Any greasy surface should be cleaned with a strong ammonia solution and then allowed to dry completely.

For drywall preparation countersink all nail heads. Tape or repair all joints or holes using joint tape or a wall patch and joint compound and then let dry. Sand the wall to a smooth finish.

Prime all new drywall with a wallpaper primer/sealer and follow primer instructions for the dry time (normally 24 hours).

Apply sizing to walls and let dry.

avoiding show-through

If the walls to be covered have highly contrasted colors or white patches on dark wall, lining paper should be applied to avoid show-through. Instead of lining paper, you may also prime over the contrasting areas until the entire area has a uniform color.

dealing with mold or moldew

Any area with mold or mildew should also be prepared before application. Wash any mold or mildew areas with chlorine bleach (1cup Clorox® to 3 quarts water). Rinse clean and then let dry.

before you apply wallcovering

Extreme caution should be used when trimming or hanging wallcovering around electrical outlets. Turn off ALL electrical current to room at the fuse or circuit box.

tools you may need

sturdy step stool or stepladder
razor blade knife and extra blades
tape measure
level or plumb bob
yardstick or straight edge

clean sponge or soft cloth
clean water and a water tray
drop cloth
large plastic trash bags



application

Use a wallcovering adhesive that is strippable, dries clear, and cleans up with water before it dries. Recommended brands include the following: Romans 880, Sure Grip Plus or equivalents. Also, look for an adhesive that is mold and mildew resistant if you intend to hang your wallcovering in an area susceptible to mold/mildew (basements, bathrooms, humid locations). If you accidentally apply wallcovering adhesive to the face of your wallpaper, remove it with a clean, wet sponge and then dry with a clean, lint-free towel.

Trim your mural with a clean, single edge razor blade or a sharp pair of scissors. **Murals with multiple panels are printed with approximately 1 inch of bleed for overlapping and double-cutting the seam.**

To double-cut the seam, overlap the panels to find the pattern match. Cut through both layers using a very sharp blade and peel the top strip back. Peel the bottom strip off the wall and adhere the top strip back in place on the wall for a perfectly fitted seam.

Option 1: Pasting the Wall

Apply a thin coat of wallcovering adhesive to the wall. Mist the back of the wallcovering with warm water. "Book" the wallcovering by folding it **without creasing it**, wet side to wet side (bring in both edges toward the middle), and allow it to relax for 5 minutes. Apply wallcovering directly to pasted wall.

Option 2: Pasting the Wallcovering

Using a 1/2" nap roller, apply paste to the back of the wallcovering. "Book" the wallcovering by folding it without creasing it, pasted side to pasted side (bring in both edges toward the middle). Loosely roll and put into a large plastic trash bag, along with a damp cloth, again taking care not to crease folds. This maintains a humid environment to prevent the wallpaper from drying out. Allow to relax in the bag for 5 minutes.

Wallcovering is very strong when wet; however we recommend that you do not apply a great deal of side-to-side pressure when applying the material. We also recommend using a "smoothing" brush to remove air pockets or paste lumps. Work air pockets or paste outward toward the edges. If you are using a squeegee, always use a plastic blade instead of a metal blade as metal may tear through the material or damage the printed surface.

cleaning your wallcovering

Sponge-clean your wallcovering. Use a lukewarm, mild detergent solution. Do not use abrasive cleaners containing chlorine bleach, solvents, or ammonia as they may attack and damage the printed surface.

****Caution****

**Plastic bag may be
a choking hazard
KEEP AWAY FROM SMALL
CHILDREN**



4700 Lakeside Avenue
Third Floor
Cleveland, Ohio 44114
1-800-496-4444

service@4walls.com

Limited Warranty: *The manufacturer warrants that for a period of two (2) years from the date of shipment that its wallcovering products will conform to their product specifications and will be free from defects in excess of those permitted by their product specifications. THE MANUFACTURER DISCLAIMS ALL OTHER REPRESENTATIONS AND WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. If any product sold by manufacturer fails to conform to the above warranty, manufacturer shall supply replacement product free of charge. The supply of replacement product is the exclusive remedy and is the limit of the manufacturer's liability. In no event shall the manufacturer be liable for incidental or consequential damages.*